

This Page Is Inserted by IFW Operations
and is not a part of the Official Record

BEST AVAILABLE IMAGES

Defective images within this document are accurate representations of the original documents submitted by the applicant.

Defects in the images may include (but are not limited to):

- BLACK BORDERS
- TEXT CUT OFF AT TOP, BOTTOM OR SIDES
- FADED TEXT
- ILLEGIBLE TEXT
- SKEWED/SLANTED IMAGES
- COLORED PHOTOS
- BLACK OR VERY BLACK AND WHITE DARK PHOTOS
- GRAY SCALE DOCUMENTS

IMAGES ARE BEST AVAILABLE COPY.

**As rescanning documents *will not* correct images,
please do not report the images to the
Image Problem Mailbox.**

METHOD FOR PRODUCING A GLUTEN-FREE PEPTIDE PREPARATION
AND PREPARATION THUS OBTAINED

The present invention relates to a method for
5 producing a peptide preparation that is both glutamine-
rich and gluten-free and to the preparation thus
obtained. The invention also relates to the use of the
preparation in various products and to the products
containing the preparation.

10 Gluten is a combination of proteins found in
the endosperm of various grains, such as wheat, barley
and rye, oats and other gluten-containing wheat variants,
such as triticale, spelt and kamut. In wheat, gluten
accounts for 90% of the protein and makes up almost 15%
15 of the total weight of a grain. It is thus an important
source of protein.

However, gluten is the cause of a genetic
disorder known as coeliac disease or gluten intolerance.
Symptoms of coeliac disease can range from the classic
20 features, such as diarrhea, weight loss, and
malnutrition, to latent symptoms such as isolated
nutrient deficiencies. The disease mostly affects people
of European descent, and occurs more rarely in black and
Asian populations. Those affected suffer damage to the
25 villi (shortening and villous flattening) in the lamina
propria and crypt regions of their intestines when they
eat specific food-grain antigens (toxic amino acid
sequences) that are found in wheat, rye, and barley, oats
and other gluten-containing wheat variants, such as
30 triticale, spelt and kamut. The gluten found in rice and
corn do not cause the intolerance.

For persons with coeliac disease the toxic part
of the gluten molecule is the prolamins portion: gliadin
in wheat, secalin in rye and horedin in barley. Following
35 a gluten-free diet, people can recover from the symptoms
of the disease, but they cannot be cured. Re-introduction
of gluten in the diet will again lead to symptoms.

Glutamine is an amino acid that occurs abundantly in gluten. Although it is not an essential amino acid it is nevertheless desirable for certain individuals, in particular those who are recovering from surgery, suffering from gastrointestinal disorders, immune function deficiencies, metabolic stress states, shock or performing endurance sports. Such individuals would benefit from supplementation with this amino acid, for example by taking a peptide preparation rich in glutamine.

Gluten is a very cost-effective source for such glutamine-rich peptide preparations. However, the known preparations are not suitable for coeliac patients since they still contain the toxic parts of the gliadin.

It is therefore the object of the present invention to provide a peptide preparation that is rich in bound glutamine but at the same time gluten free.

Such peptide preparation can be obtained by a method, comprising the steps of:

- a) enzymatically hydrolysing gluten using one or more proteases to obtain a hydrolysate;
- b) acidifying the hydrolysate to a pH between 4 and 5; and
- c) filtering the hydrolysate to obtain the glutamine-rich gluten-free peptide preparation as the filtrate.

The term "gluten-free" is intended to indicate that the product when tested in an ELISA based on anti- α -gliadin antibodies yields a value of < 200ppm. A suitable ELISA to test the gluten-free property is as described in the Association of Official Analytical Chemists' (AOAC's) Official Methods of Analysis, 15th Edition, 2nd supplement (1991).

It is clear that the proteases to be used can be selected from a wide range of proteases known in the art provided that hydrolysis performed with such protease results in a preparation that yields < 200 ppm in the above described ELISA. Proteases include acid, basic and

neutral proteases derived from bacterial, fungal, animal or botanical sources. It was found that basic or neutral proteases active at a pH above 6 are particularly well suited. Examples of such proteases are Proleather N (Amano), Neutrase (NOVO), PROMOD 192P (Biocatalysts), Alcalase 2.4L (NOVO), Protease S (Amano), Peptidase A (Amano), Peptidase R (Amano). Of these the following proteases are preferred: Proleather N (Amano) and Alcalase 2.4L (NOVO).

10 The protein fragments that cause the hypersensitivity in coeliac patients are surprisingly removed when the hydrolysate is acidified and subsequently filtered. It is assumed that these fragments are precipitated and remain in the retentate of the 15 filter. The pH to which the hydrolysate is to be acidified lies between 4 and 5, preferably between 4.1 and 4.9, more preferably between 4.3 and 4.8, most preferably between 4.5 and 4.7, and is optimally 4.6.

Hydrolysis is an essential step in the method 20 of the invention as without hydrolysis the toxic fragments cannot be removed.

Peptide preparations that are obtainable by the method of the invention consisting of peptides that do not induce gluten hypersensitivity symptoms in coeliac 25 patients are a further aspect of this invention. Such preparations are suitable as a food additive or food stuff for supplying additional glutamine to a subject. The preparation thus has sports and clinical applications and can be used in enteral nutrition and pet food.

30 The peptide preparation of the invention can be used in further products that can be taken by or administered to subjects in need of supplementation. Particular embodiments of such products are glutamine peptide tablets comprising the usual carriers, diluents 35 and excipients for tablets and a peptide preparation of the invention as glutamine peptide source, glutamine peptide liquid beverage comprising the usual ingredients for beverages and a peptide preparation of the invention

as glutamine peptide source, and glutamine peptide enteral nutrition comprising the usual carriers, diluents and excipients for enteral nutrition and a peptide preparation of the invention as glutamine peptide source.

5 Although the invention is more broadly applicable to gluten from all grains that may cause coeliac disease, it is preferred to use wheat because of its high glutamine content.

 The present invention will be further
10 elucidated in the following examples that are given for illustration purposes only and are in no way intended to limit the scope of the invention.

EXAMPLES

15 EXAMPLE 1

Production of a glutamine-rich, gluten-free peptide preparation

A series of experiments was carried out to illustrate the critical process parameters.

20 A series of peptide hydrolysates was produced by heating deionized water to a temperature of $63^{\circ}\text{C} \pm 1^{\circ}\text{C}$. To this water, a mix of 45% liquid potassium hydroxide, 50% liquid sodium hydroxide, hydrated calcium hydroxide in a ratio of 1:0.78:0.70, respectively, is
25 added to obtain a pH suitable for the protease to be used.

Vital wheat gluten ("VWG", Cargill B.V., Bergen op Zoom, Netherlands) is added to this solution to produce a 12% solids mix of solubilized gluten.

30 Hydrolysis is performed with a desired protease as indicated in the description of the separate experiments hereinbelow. The hydrolysis reaction is performed for 3 hours at a temperature that is suitable for the protease used, usually $60^{\circ}\text{C} \pm 2^{\circ}\text{C}$.

35 After the hydrolysis, acid, in particular sulphuric acid is added to achieve the desired pH (see description of experiments) with agitation. The reaction is stopped by a HTST (high temperature short time)

heating at $116^{\circ}\text{C} \pm 2^{\circ}\text{C}$. Subsequently the solution is cooled to $66^{\circ}\text{C} \pm 2^{\circ}\text{C}$ and filtered using diatomaceous earth (Eagle-Picher Minerals Inc., Reno, NV, USA) at 40% bodyfeed. The solution is recirculated through the filter
5 press for a minimum of 3 minutes.

The pH of the filtrate is adjusted to 6.4-6.8 by means of an alkaline solution. After evaporating the liquid and drying, a powdered peptide preparation of the invention is obtained.

10 In order to test whether the product is gluten-free an ELISA was performed according to AOAC 991.19 (Official Methods of Analysis (1990) 15th Edition, 2nd Supplement (1991)).

The bound glutamine content was determined
15 according to P.E. Wilcox, "Determination of Amide Residues by Chemical Methods." Methods of Enzymology 11, 63-76 (1967).

A measure for the degree of hydrolysis of protein is the AN/TN ratio. AN is the amino-nitrogen
20 level, which can be determined using the formol titration method, or according to J. Adler-Nissen, Enzymatic hydrolysis of food proteins. Elsevier Applied Science Publishers, 1986. TN is the total amino-nitrogen content which is determined according to the Kjeldahl nitrogen
25 determination method. The higher the ratio AN/TN, the higher the degree of hydrolysis of the protein preparation.

30 Experiments

Experiment 1

Wheat gluten is dispersed in water. The pH is adjusted to 4.6 with sulphuric acid and the solution filtered.

35 Experiment 2

Wheat gluten is dispersed in water. The pH is adjusted to 3.2-3.4 with sulphuric acid. The gluten is digested using

Acid Protease II (Amano). The enzyme is heat inactivated and the solution is filtered.

Experiment 3

5 Wheat gluten is dispersed in caustic water. The gluten is digested using the alkaline and neutral proteases Alcalase 2.4L (NOVO) and Proleather N (Amano), and amylases BAN 240L (NOVO). After inactivation of the enzyme the pH is adjusted to near neutral with sulphuric
10 acid and the solution is filtered.

Experiment 4

Wheat gluten is dispersed in caustic water. The gluten is digested using the alkaline and neutral proteases
15 Alcalase 2.4L (NOVO) and Proleather N (Amano). The pH is adjusted to 3.8-4.1 with sulphuric acid. After heat inactivation of the enzyme the solution is filtered. The pH is then adjusted to neutral with caustic.

Experiment 5

Wheat gluten is dispersed in caustic water. The gluten is digested using the alkaline and neutral proteases Alcalase 2.4L (NOVO) and Proleather N (Amano). The pH
20 adjusted to 6.5 with sulphuric acid. After heat inactivation of enzymes, the solution is filtered. The pH
25 is adjusted to neutral using caustic.

Experiment 6

Wheat gluten is dispersed in caustic water. The gluten is
30 digested using the alkaline and neutral proteases Alcalase 2.4L (NOVO) and Proleather N (Amano). The pH is adjusted to 4.3 with sulphuric acid. After heat inactivation of enzymes and filtration, the pH is adjusted to neutral using caustic.

35

Experiment 7

Wheat gluten is dispersed in caustic water. The gluten is digested using the alkaline and neutral proteases

Alcalase 2.4L (NOVO) and Proleather N (Amano). Subsequently the pH is adjusted to 4.5 with sulphuric acid. After heat inactivation of enzymes and filtration, the pH is adjusted back to neutral using caustic.

5

Experiment 8

Wheat gluten is dispersed in caustic water. The gluten is digested using the alkaline and neutral proteases Alcalase 2.4L (NOVO) and Proleather N (Amano). The pH is
10 adjusted to 4.6 with sulphuric acid. After heat inactivation of enzymes the solution is filtered. Then the pH is adjusted to neutral using caustic.

Experiment 9

15 Wheat gluten is dispersed in caustic water. The gluten is digested using the alkaline and neutral proteases Alcalase 2.4L (NOVO) and Proleather N (Amano). The pH is adjusted to 4.8 with sulphuric acid. After heat inactivation of enzymes and filtration, the pH is
20 adjusted to neutral using caustic.

Table 1 shows the result of the experiments. It is clear from the above example that both hydrolysis of the gluten and filtration at an acid pH are essential for
25 the product to be gluten free.

Table 1

Sample	AN %	Gluten (ppm)	Bound Glutamine (%)
5 1	0,5	1200	19
2	0,67	>320	31
3	1,4	438	25
4	1,62	300	25
5	1,59	310	27
10 6	1,7	<20	28
7	2,03	<20	27
8	1,95	<20	26
9	1,96	<20	27

TN=13%

15

EXAMPLE 2

Application of gluten-free glutamine-rich peptide
preparation of the invention

In the following, three examples of
20 applications for the preparation of the invention are
given.

1. Glutamine Peptide Tablets

Ingredients:

- 25 (1) Enzymatically Hydrolysed Wheat Protein (granular)
(preparation according to the invention
(2) Pharmacel 102
(3) CAB-O-SIL M-5

30 Recipe:

Enzymatically hydrolyzed wheat protein (1)	91.1%
Microcrystalline cellulose (2)	5.0%
Di-calcium phosphate	2.0%
Silicon Dioxide (3)	0.9%
35 Stearic Acid	0.5%
Magnesium Stearate	0.5%

Total

100 %

Preparation method:

The powders are premixed (withholding the Mg Stearate until the last minutes of mixing). The tablets are prepared by direct compression.

5

Properties of the tablets:

Glutamine Peptide per tablet	170	mg
Tablet weight	758	mg
Tablet length (Oblong)	19.04	mm
10 Compression pressure	13.3	kN
Hardness	140	N

2. Glutamine Peptide Liquid Beverage

Ingredients:

- 15 (1) Enzymatically hydrolyzed wheat protein (preparation of the invention)
 (2) Enzymatically hydrolyzed whey protein (WE80BG, DMV International)
 (3) Grapefruit Flavor Tastemaker 946068

20

Recipe:

Water (QS to 1 liter)	920.00g
Enzymatically Hydrolyzed Wheat Gluten (1)	13.21g
Enzymatically Hydrolyzed Whey (2)	13.04g
25 Sucrose	26.60g
Glucose	15.00g
Fructose	5.00g
Glucose Polymers (Maltodextrin DE18)	10.00g
Malic Acid	3.33g
30 Citric Acid	0.67g
Sodium Citrate	1.00g
Grapefruit Flavor (3)	0.60g
Aspartame	0.10g
Acesulfame Potassium	0.10g
35	1000.0 ml

Preparation method:

All ingredients are added to the water and mixed well. The acids are added last to achieve a pH of 3.9. The liquid is bottled, heat processed for 1 min. at 85°C and cooled.

Nutrition Facts (per 100 ml):

Protein	2.09	g
Glutamine Peptide	0.26	g
10 Carbohydrates	6.0	g

3. Clinical Enteral Nutrition Prototype with Glutamine Peptide and Whey Peptides

Ingredients:

- 15 (1) Enzymatically hydrolyzed wheat protein (preparation of the invention
(2) Enzymatically hydrolyzed whey protein (WE80BG, DMV International)

20 Recipe:

Water (QS to 1 liter)	720.00g
Enzymatically Hydrolyzed Wheat Gluten (1)	40.00g
Enzymatically Hydrolyzed Whey (2)	35.60g
Food Starch, Modified	84.00g
25 Maltodextrin	59.00g
Soy Oil	30.00g
MCT Oil	10.00g
Potassium Citrate	2.20g
Sodium Citrate	1.60g
30 Magnesium Chloride	3.20g
Calcium Phosphate	2.80g
Potassium Phosphate	2.00g
Sodium Phosphate	1.00g
Carrageenan	0.50g
35	1000.0 ml

Preparation method:

The minerals are dissolved in water with constant stirring. The premixed carbohydrates are added to the mixture. The mixture is heated to 70°C and held for 10 minutes with constant stirring. The protein is added to the mixture, which is then heated to 70°C with constant stirring. The oil is added to the mixture, which is then mixed well. The mixture is then double homogenised at 4000 psig (276 bar). The pH is adjusted to the appropriate value. The solids content is adjusted to an appropriate value. The product is sterilised and the heat process retorted at 121°C for 10 minutes.

Nutrition Facts (per 100 ml):

15 Protein	6.0 g
Glutamine Peptide	1.0 g
Carbohydrates	13.8 g
Fat	4.0 g